

SPRAY CARBURETOR

CARBURETOR CLEANER

Description

Carburetor cleaner. Cleans air passages, inlet flap, venturi tube, seats of adjustment screws and carburettor housing. For all 2 and 4-stroke gas engines. Tested for use with catalyts.

Advantages

- cleans

Use

Remove air cleaner, spray into intake manifold. Start engine. Spray on throttle valves, air nozzles and lines etc. Actuate throttle pedal in bursts. Shake before use.

Contents

500 ml

